

INSTALLATION GUIDE

**2020 - CURRENT
FORD POLICE INTERCEPTOR UTILITY
CARGO SECURITY COVER
CSC47UINT20**

Pro-gard[™]
PRODUCTS LLC.

STRONG. RELIABLE. SECURE.

Note: The installation of this product requires either the Pro-gard B4702UINT20 barrier or the Pro-gard B4705UINT20 barrier.

I. The following tools will be required to complete the installation

- A. 7/16 wrench
- B. Phillips screwdriver

II. Read all instructions and refer to the Parts List on the last page to ensure all parts were received.

WARNING: *Locate all wiring, fuel lines, brake lines, coolant lines, and refrigerant lines before drilling any holes or installing any self-drilling fasteners.*

III. Barrier installation

- A. Install barrier (B4702UINT20 or B4705UINT20) per the barrier installation manual.

IV. Barrier prep for Cargo Security Cover

- A. Remove the (6) Phillips head screws and nuts that run horizontal across the bottom of the barrier screen/window.
- B. Keep the screws as you will re-use them in a later step. The nuts will not be re-used.

V. Attach support bracket to barrier

- A. Take the (6) Phillips head screws that you previously removed from the barrier and attach the CSC Support Bar Weldment [3CSC472009] to the barrier utilizing the horizontal row of holes in the bottom of the screen/window.

VI. Attach top panels to support bracket

- A. Place the CSC Top Panel, Passenger [3CSC472003] on top of the CSC Support Bar Weldment [3CSC472009] that is attached to the back of the barrier. Support the rearwards most end of it so that the panel sits horizontal.
- B. Using the (4) of the Phillips screws [3X03] that are located in the CSC Hardware Kit [3CSK472000] loosely attach the CSC Top Panel, Passenger [3CSC472003] to the CSC Support Bar Weldment [3CSC472009].
- C. Repeat for drivers side of vehicle using CSC Top Panel, Driver [3CSC472004].

VII. Attach rear support bar

- A. With the CSC Top Panels supported horizontally attach the CSC Support Weldment [3CSC472005] to the bottom at the rear of the panels. You will use (6) of the Phillips screws [3X03] and 6 of the serrated flange nuts [3X612] from the CSC Hardware Kit [3CSK472000] for this.
- B. Now that the CSC Support Weldment [3CSC472005] is attached to the CSC Top Panels you will need to attach it to the car itself. Make sure the CSC Top Panels are sitting horizontal and use the (4) #8 x 2" sheet metal screws [3x618] from the CSC Hardware Kit [3CSK472000] to go through the four holes in outer edges of the CSC Support Weldment [3CSC472005] and into the "D" pillar of the vehicle. Utilize a 1/4" socket and impact driver for this step.

VIII. Attach the CSC support panels to each other

- A. Utilizing (8) Phillips screws [3X03] and (8) serrated flange nuts [3X612] from the CSC Hardware Kit [3CSK472000] bolt the CSC Top Panels together along the lower spine underneath the CSC Top Panels.
- B. At this time you can tighten up the (6) Phillips screws [3X03] that were used to attach the CSC Top Panels to the Support Bar Weldment [3CSC472009] at the back of the barrier.

IX. Installing the rubber top cover

- A. Remove the (6) Phillips screws [3X03] and the (6) serrated flange nuts [3X612] that were used to attach the CSC Support Weldment [3CSC472005] to the CSC Top Panels. Leave the CSC Top Panels sitting on top of the CSC Support Weldment [3CSC472005] .
- B. Place the CSC Rubber Top Cover [4CSC472010] on top of the CSC Top Panels. This part is handed and the holes will only line up in one orientation.
- C. Use the (9) nylon push-in rivets [3X246] from the CSC Hardware Kit [3CSK472000] to secure the CSC Rubber Top Cover [4CSC472010] to the CSC Top Panels. There are pre-drilled holes in the CSC Rubber Top Cover [4CSC472010] that will line up with the underlying holes in the CSC Top Panels.

IX. Install the Top Panel assembly

- A. Set the CSC Top Panel Assembly [3CSC472011] on top of the CSC Rubber Top Cover [4CSC472010] towards the rear of the vehicle.
- B. Using the (6) Phillips screws [3X03] and the (6) serrated flange nuts [3X612] that were used to attach the CSC Support Weldment [3CSC472005] to the CSC Top Panels previously bolt the CSC Top Panel Assembly [3CSC472011] on top of the CSC Rubber Top Cover [4CSC472010].

Installation complete

If you have any problems with this installation or have any questions please call (800-480-6680) and ask for technical assistance.

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	3CSC472009	A CSC SUPPORT BAR WELDMENT
2	1	3CSC472003	E CSC TOP PANEL, PASSENGER
3	1	3CSC472004	E CSC TOP PANEL, DRIVER
4	1	3CSC472005	A CSC SUPPORT WELDMENT
5	1	4CSC472010	B CSC RUBBER TOP COVER
6	1	3CSC472011	A CSC TOP PANEL ASSEMBLY
7	1	3CSK472000	B CSC HARDWARE KIT

