

# **INSTALLATION GUIDE**

**SAFESTOP VEHICLE  
ANTI-THEFT SYSTEM**

**SS0006**

**2006-CURRENT**

**CHEVY IMPALA**

**Pro-gard**<sup>™</sup>  
PRODUCTS LLC.

**STRONG | RELIABLE | SECURE**

**pro-gard.com  
800.480.6680**

# SS0006 for 2006-Current Chevy Impala

## **I. Line Location**

- A. Remove driver side kick panel and/or steering wheel column to allow for easy access.
- B. Locate ignition switch connector, typically located at the rear of the ignition key switch at the steering wheel column.
- C. Locate a constant 12V power supply that can handle a 10A circuit, but nothing greater. The main power line heading into the ignition connector should be used. It can be identified by a thicker gauge wire that has a constant 12V output. See Table 1.
- D. Locate an area on the vehicle chassis where the SS0006 will eventually have the ground wire attached. It is not recommended that the SS0006 ground wire be shared with any other component, so common ground wires should be avoided.
- E. Locate a brake light line that gives a 12V output when the brake is pressed. This can be found on the BCM under the kick panel. See Table 2.
- F. Locate the shift lock actuator line. This can be found on the BCM under the kick panel. See Table 2.
- G. The SS0006 provides an optional feature allowing the trunk release button to be disabled. If this feature is desired, then locate the trunk latch line that gives 12V output when the trunk latch button is engaged. This can be found on the BCM under the kick panel. See Table 2.
- H. Once all of the aforementioned lines have been identified, disconnect the battery and wait 20 minutes for any stored capacitance to discharge.

## **II. Line Cutting & Splicing**

- A. Disconnect the 6-pin OEM ignition harness connector from the back of the ignition switch in the steering wheel column, and connect the SS0006 harness connectors into their corresponding OEM ignition harness connectors (Be aware that there is a red locking tab on the OEM and SS0006 connectors).
- B. Cut the shift lock actuator line, and strip both ends. Attach the YELLOW wire from the SS0006 SHIFT DISABLE harness to one end of the shift lock actuator line. Attach the YELLOW/BLACK wire from the SS0006 SHIFT DISABLE harness to the other end of the shift lock actuator line (Polarity/orientation is irrelevant for this circuit). See Figure 1.

- C. If the optional SS0006 trunk disable feature is going to be used, then cut the trunk latch actuator line and strip both ends. Attach the BLUE wire from the SS0006 TRUNK DISABLE harness to one end of the trunk latch actuator line. Attach the BLUE/WHITE wire from the SS0006 TRUNK DISABLE harness to the other end of the trunk latch actuator line (Polarity/orientation is irrelevant for this circuit). See Figure 1.
- D. Splice the GREEN/WHITE wire from the SS0006 harness into the brake light line (T-tap). See Figure 1.
- E. Splice the RED wire from the SS0006 harness into the constant 12V ignition power supply (T-tap). See Figure 1.
- F. If there is a desire to use the optional SS0006 gunlock output wire, then simply attach the BROWN SS0006 wire to the gunlock timer input wire (see gunlock timer installation manual for details). If this feature is not needed, simply cap off the BROWN wire with heat shrink or another type of wire insulator. See Figure 1.
- G. Attach the BLACK wire from the SS0006 harness to the isolated vehicle chassis point. See Figure 1.


### **III. Testing**

- A. Reconnect the battery.
- B. Test SS0006 for full functionality:
  - SS0006 unit test:
    1. Start vehicle.
    2. Turn SS0006 toggle switch on (red LED illuminated).
    3. Turn key to off and remove from ignition switch. Vehicle should keep running.
    4. Turn SS0006 toggle switch off (red LED not illuminated). Vehicle should shut down.
  - SS0006 brake pedal override:
    1. Start vehicle.
    2. Turn SS0006 toggle switch on (red LED illuminated).
    3. Turn key to off and remove from ignition switch. Vehicle should keep running.

4. Depress brake. Vehicle should shut down.
- SS0006 gun lock override:
    1. Start vehicle.
    2. Turn SS0006 toggle switch on (red LED illuminated).
    3. Activate momentary switch for gunlock. Gunlock should disengage for 8 seconds, before reengaging.
    4. Turn key to off and remove from ignition switch, and immediately activate momentary switch for gunlock. Gunlock should disengage for 8 seconds, before reengaging. After that, the gunlock should not be able to disengage anymore until the key is reinserted back into the ignition.
  - SS0006 trunk disable override:
    1. Start vehicle.
    2. Turn SS0006 toggle switch on (red LED illuminated).
    3. With keys in ignition, activate the trunk release latch. Trunk should release.
    4. Close trunk.
    5. Remove keys from ignition. While vehicle is still running, try activating the trunk release hatch. Trunk should not release.

- C. After successful test verification, it is recommended that the SS0006 module be mounted securely to a solid location in or around the steering column. A  $\frac{3}{4}$ " hole will need to be drilled in order to mount the SS0006 toggle switch, preferably in a location where the toggle switch will be in plain view on a cosmetically friendly surface. Harnesses should be coiled and secured away from any sharp metallic edges.

Figure 1



**Table 1**  
**Chevy Ignition**

Model	Year	Key-Sense		Accessory-Run		Run-Start		V-Ref		12V Constant Power		
		Pin #	Wire Color	Pin #	Wire Color	Pin #	Wire Color	Pin #	Wire Color	Pin #	Wire Color	
Tahoe	2007-2014	Plug & Play									4	RED/WHT
Tahoe	2015	Plug & Play									4	RED/BLU
Silverado	2007-2013	Plug & Play									4	RED/WHT
Silverado	2014-2015	Plug & Play									4	RED/BLU
Suburban	2007-2014	Plug & Play									4	RED/WHT
Suburban	2015	Plug & Play									4	RED/BLU
Express	2007	Plug & Play									B	RED/BLK
Express	2008-2015	Plug & Play									4	RED/WHT
Impala	2007-2016	Plug & Play									2	RED/WHT
Caprice	2011-2013	Plug & Play									2	ORG/BLK
Caprice	2014-2016	Plug & Play									2	RED/WHT
Tahoe	2016-2017	6	WHT/BLK	3	VIO/YEL	2	VIO/BLK	5	WHT/VIO	4	RED/BLU	
Silverado	2016-2017	6	WHT/BLK	3	VIO/YEL	2	VIO/BLK	5	WHT/VIO	4	RED/BLU	
Suburban	2016-2017	6	WHT/BLK	3	VIO/YEL	2	VIO/BLK	5	WHT/VIO	4	RED/BLU	
Express	2016-2017	5	PNK	3	BRN	2	PNK	6	WHT/VIO	4	RED/WHT	

**Table 2**  
**Chevy BCM**

Model	Year	Shift Disable			Trunk Disable			Brake Light Signal		
		Connector Color	Pin #	Wire Color	Connector Color	Pin #	Wire Color	Connector Color	Pin #	Wire Color
Tahoe	2007	GRN	26	TAN/WHT	YEL	1	YEL	BRN	5	LT BLU
Tahoe	2008-2014	GRN	26	TAN/WHT	GRY	1	YEL	BRN	5	LT BLU
Tahoe	2015	GRY	6	YEL/WHT	BRN	20	YEL	BLK	11	YEL/WHT
Tahoe	2016-2017	GRY	6	YEL/WHT	BRN	20	YEL	BLK	11	VIO/WHT
Silverado	2007-2013	GRN	26	TAN/WHT	-	-	-	BRN	5	LT BLU
Silverado	2014-2017	GRY	6	YEL/WHT	-	-	-	BLK	11	VIO/WHT
Suburban	2007-2014	GRN	26	TAN/WHT	GRY	1	YEL	BRN	5	LT BLU
Suburban	2015-2017	GRY	6	YEL/WHT	BRN	20	YEL	BLK	11	VIO/WHT
Express	2007	BLK	1	LT GRN/BLK	-	-	-	BLK	2	LT BLU
Express	2008-2017	GRN	26	TAN/WHT	-	-	-	PNK	2	LT BLU
Impala	2007-2013	GRN	26	DK GRN/WHT	GRY	2	LT BLU	BRN	5	LT BLU
Impala	2014-2017	GRY	6	YEL/WHT	PNK	5	VIO/GRY	BLK	11	VIO/WHT
Caprice	2011-2013	WHT	22	DK GRN/WHT	BLK	22	BRN	PNK	2	LT BLU
Caprice	2014-2017	GRY	6	VIO/BLK	BLK	8	GRY/YEL	BLK	11	VIO/WHT